


2010 Lexus GS 450h V6-3.5L (2GR-FSE) Hybrid

Vehicle > Locations > Connectors

## ENGINE COMPARTMENT - POSITION OF PARTS

### Engine Compartment - Position Of Parts

**Locations:** The locations of components, connectors, ground points, and splices referred to within these diagrams can be found at Vehicle / Locations.



- 1 -


---

**Position of Parts in Engine Compartment**


---

- A 1 Airbag Sensor (Front LH)
- A 2 Windshield Washer Motor
- A 3 Headlamp Cleaner Motor
- A 4 Water Level Warning SW
- A 5 Headlamp Cleaner Control Relay
- A 8 Junction Connector
- A 9 Junction Connector
- A 10 Junction Connector
- A 11 Junction Connector
- A 12 Absorber Control Actuator (Front LH)
- A 13 Skid Control ECU
- A 14 Skid Control ECU
- A 15 Skid Control ECU
- A 16 Brake Actuator
- A 17 Junction Connector
- A 18 Wireless Door Lock Buzzer
- A 19 Windshield Wiper Motor
- A 20 Height Control Sensor (Front)
- A 21 Brake Stroke Simulator Cylinder
- A 22 Brake Fluid Level Warning SW
- A 23 Power Steering ECU
- A 25 Airbag Sensor (Front RH)
- A 26 Absorber Control Actuator (Front RH)
- A 27 Security Horn
- A 41 Short Connector (Brake Stroke Simulator Cylinder)
- A 42 Short Connector (Brake Stroke Simulator Cylinder)
- A 45 Fuel Pump Resistor
- A 49 Water Pump Motor (Inverter)
- A 50 Junction Connector
- A 53 Engine Control Module
- A 54 Hybrid Vehicle Control ECU
- A 55 Oil Pump Motor Controller
- A 56 Water Pump Motor (A/C)
- A 58 Front Stabilizer Control ECU
- A 59 Junction Connector
- A 60 Inverter
- A 64 Front Wiper Deicer

Position of Parts in Engine Compartment



Position of Parts in Engine Compartment



Position of Parts in Engine Compartment

