




DIGITAL INPUTS 12V




EEPROM MEMORY




POWER SUPPLY




EXTERNAL CAN BUS




EXTERNAL CAN BUS N0.2




LIN BUS (USART1)




CAN BUS N0.3 HS/SW/FT CAN




THROTTLE INPUTS




BRAKE INPUT




GEAR FEEDBACK INPUTS




GP ANALOG INPUTS




STM32F107 CPU




DIGITAL OUTPUT DRIVER




CONNECTOR 56 WAY




TOYOTA INVERTER COMS




RS232




TOYOTA GEARBOX TEMPS



ESP WiFi MODULE



PWM OUTPUTS



ANALOG OUTPUTS

